

Silicon Mould Mix

Take equal parts of both compounds and knead together until there is no marbling.



Shape the ready mixture to accommodate whatever is leaving the impression and press the object in to the mix. Leave to set (5-10mins). Gently remove the object. Over kneading as well as unequal mixtures may cause the mould to set too quickly or not at all.



Condition your Art Clay Silver, lightly oil your newly made mould and press the Art Clay Silver in to the mould. At this stage you can either trim away any excess clay and then leave to dry in the mould or gently remove the clay from the mould, trim and then dry. Sand, fire and polish to finish.